# AVYCON®

AVC **NSZ81X04SPL**

QUICK START GUIDE

CAMERA INSTALLATION

1. Installation

Wall Mount

Step 1: Stick the mounting template to the wall, drill 4 screw holes and 1 tail cable hole.


Step 2: Hammer the 4 anchor into the drilled wall holes.

Step 3: Align the camera bracket with the 4 swelling colloidal particles screw holes, and lock the screws to fix it.

Ceiling Mount

Step 1: Stick the mounting template to the wall, drill 4 screw holes and 1 tail cable hole.

Wall

Anchor

**Step 2:** Hammer the 4 anchor into the drilled wall holes.

Wall

Camera bracket

Screws

Step 3: Align the camera bracket with the 4 swelling colloidal particles screw holes, and lock the screws to fix it.

Installation Method

| Wall Mount	Ceiling Mount

2. Camera Connection Diagram

Attention:There are two connection modes:

1. For non-PoE router,pls connect the camera by a PoE switch or a PoE injector.

2. For a POE NVR,pls connect the camera directly to the POE NVR, then follow the below steps.

3. Install the App

There are two methods to install the App.

• Search for "AVY Mobile One" in App Store or Google Play.

• Scan the QR code below to download the App.

For iOS

For Android

3

4. Camera Settings

Open "AVY Mobile One", you will see the following interface to add the cameras.

1. Click menu

2. Click Device List

*When choose Manual Add, input the correct camera information.

If add the device successfully, you will see the following interface.

Please refer to "Help" section for more detailed instruction.

5. In Windows

1. Log in to the website www.al8.co and click "Device Search for Windows" to download "AVYCON Device Tool", it will help to search all the available devices on your local network.

2. Under "AVYCON Device Tool", you can modify the information of a selected device. Including IP, Media Port, Web Port, Gateway, Net Mask, Net Mode.
(The default username & password is: admin & admin)

3. Open the Internet Explorer and input the device's IP address; Input the username & password in the following interface to log in to the device.

4. After login, click "Remote Setting" to change the setting.

6. MAC OS

1. Open your router web interface and log in.

2. Find the "Attached device" or "Connected device" menu. Find the device's IP address according to its MAC address. The Mac address is labeled on the device.

Picture for reference only

3. Input the device's IP address in Safari, log in with your username & password.

4. After login, click "Remote Setting" to modify the setting.

AVYCON®

AVYCON®

phone: 949-752-7606
email: info@avycon.com
social: @avycon_aivo
website: avycon.com